Doctors Man CATALOG

ic





Doctors Man Co., Ltd. 2F Leaf Utsukushigaoka Bld., 2-14-5, AOBA - KU, YOKOHAMA City, KANAGAWA PRF Japan 225-0002 http://www.doctorsman.com









As a pioneer in hydrogen industry, Doctors Man's declaration is:

develop safe and effective products, create correct hydrogen business environment based on scientific facts, and let people have tomorrow's health.

"Antioxidant hydrogen will become the trump card of human health in the future"

" I hope patients drink hydrogen water every day"

This doctor's advice prompted us, we have begun our challenges since then.

Since inception, we have been continuously listening to customers' voices and needs and developing various unique hydrogen products with epoch-making technology.

So far, our hydrogen products have been spread all over Japan in chain fitness facilities, hospitals, clinics, company lounges, construction sites professional athlete clubs including Olympic athletes, etc. Now our hydrogen products usage circle is constantly expanding. In addition to Japanese domestic market, we have established a solid market strategic partnership in overseas markets as well.

As a pioneer in the popularization of hydrogen, *Doctors Matt*'s dream is to allow everyone in the world to easily enjoy safe hydrogen products, contribute to therapeutic and prevention medicine areas, let more people satisfy their desire for a longer healthy life. We will continue to explore and challenge new realms.



INDEX

| Hydrogen Water Vending Machine | 4 |
|------------------------------------|----|
| Hydrogen Gas Inhaler | 6 |
| Beverage Vending Machine | 8 |
| Hydrogen Gas Injector | 10 |
| Household Hydrogen Water Generator | 12 |
| Research and Development | 14 |
| Company Profile | 18 |

Hydrogen Water **Vending Machine**

Large-size vending machines are suitable for various public places, such as gyms, yoga studios, golf clubs, hot spas, clinics, hospitals, shopping malls, health care facilities, elderly welfare facilities, hotels, restaurants, swimming pools, amusement centres, airport lounges, and so on.



Commercial use vending machine "H2 So-nano"

Hollow-fiber Membrane High Hydrogen Hydrogen Gas Gas Concentration Filter



Water intake multifunctional identification management system can be designed according to requests to manage sales

Face recognition system Fingerprint identification system Finger vein authentication system

High-definition screen can continuously play back promotional videos.

Built-in OS system Touch-sensitive high-definition LCD screen Promotional videos can be set according to needs.

H2 JV3

Large size touch-sensitive high-definition LCD screen

| H2 JV3 |
|-------------------------------------------------------------|
| W360 x D568 x H1706 |
| 95kg |
| AC100V 50 / 60Hz |
| 450W |
| Hollow-fiber membrane filter |
| Nano bubble dissolution system |
| 99.99% + (Dry state) |
| 2.4ppm (MAX3.6ppm) * |
| Built-in unique cooling system without cooling water bucket |
| 15in touch-sensitive HD LCD screen |
| |

* This data of hydrogen water concentration is provided by JHyPA (Japanese Molecule Hydrogen Promotion Association) Measuring method: Gas Chromatography (GC)




| | Any water containers are applicable |
|---|------------------------------------------------------------------------------------------------------------------------------|
| 1 | Not only our specialized vacuum H2-Bags but also any other water containers such as plastic bottles are applicable. |

performance. IC card payment system QR code-based payment system








Patented hollow-fiber membrane filter generates safe high concentration pure hydrogen water.

The patented special hollow-fiber membrane allows only hydrogen gas to permeate, so that the purity of hydrogen can reach more than 99.99%, which ensures hydrogen water safer and higher purity. Pressurized structure and special nanotechnology ensure that hydrogen water concentration is as high as 2.4-3.6ppm.



500ml hydrogen water generation only takes 20 seconds.

No concerns about long waiting line when many people drink water in facilities such as gyms, restaurants, etc.





Member management system

Membership facilities such as gyms, golf clubs, etc. can set up a management system for status of utilization.

H2 JV2



H2 JV1



| Dimension | W360 x D600 x H1580 |
|-----------------|-------------------------------------------------------------|
| Weight | 70kg |
| Rated voltage | AC100V 50/60Hz |
| Rated power | 250W |
| Hydrogen | Hollow-fiber membrane filter |
| dissolving unit | Nano bubble dissolution system |
| Purity | 99.99% + (Dry state) |
| Concentration | 2.4ppm (MAX3.6ppm) * |
| Cooling system | Built-in unique cooling system without cooling water bucket |
| HD LCD screen | Upper screen 14inch |
| | Lower screen 21inch |
| | |

| Dimension | W362 x D448 x H1733 |
|-----------------------------|----------------------------------------------------------------|
| Weight | 97kg |
| Rated voltage | AC100V 50/60Hz |
| Rated power | 250W |
| Hydrogen dissolving unit | Hollow-fiber membrane filter Nano bubble dissolution system |
| Purity | 99.99% + (Dry state) |
| Concentration | 2.4ppm (MAX3.6ppm) % |
| Cooling system | Built-in unique cooling system without cooling water bucket |
| HD LCD screen | 10.4inch |
| 0 | CD screen is equipped with an hydrogen concentration indicator |

Doctors Man Hydrogen Gas Inhaler

99.999% + Super high purity 24 hours a day 365days non-stop run 50,000 hours long service life Safe and stable advanced new technology



Dual-use Hydrogen Gas Inhaler & Injector "One Stone Two Birds"



High durability

This is the only hydrogen gas inhaler that can run 24hours a day and 365days in the world.



3 steps to operate

- 1. Turn the power on
- 2. Push the hydrogen gas
- generation button
- 3. Plug in the cannula to start
- inhalation button



In order to meet the demand for high-concentration hydrogen water, we can easily transform the inhaler into a high purity hydrogen gas injector to generate pressurized high concentration hydrogen water through a special design. Standard concentration of bottled hydrogen water can reach 3ppm-5ppm.


For special requst for a higher concentration, we can also reconsider of special design.

Mega-hydrogen Therapy









Clinic







Super High Purity Hydrogen gas purity 99.999%+



Buid-in water detector

If water quality is not qualified or water quantity is not enough, the red E (error) lamp will automatically beep and blink.

Optional Design : Hydrogen Gas Injector

Hydrogen Gas Inhaler

| Model | H2JI1 | |
|----------------|---------------------------|--|
| Purity | 99.999% + | |
| Flow | 250cc/min | |
| Max pressure | 700Kpa | |
| Rated power | 140W | |
| Rated voltage | AC100V 50/60Hz | |
| Environment | TEMP15~35°C Humidity0~80% | |
| Water tank cap | acity 2.5L | |
| Dimension | W230mm x D370mm x H1480mm | |
| Weight | 13kg | |
| | | |

This hydrogen beverage vending machine will bring you a different taste and healthy life

Variable beverage options: fresh and delicious hydrogen tea, hydrogen coffee, hydrogen mineral water

税 ۱ ۵ 🎫 💿 M 💿 HOT 1 0 H2-water For a bet bodu h Doctors Man 8

Water Cup Type Hydrogen Beverage Vending Machine

Set temperature according to personal preference



Hydrogen will become the trump card of human health in the future as an excellent selective antioxidant. Let the power of hydrogen maintain us good health and stay young and vigorous.

High concentration



Freely choose your preferred temperature and type of beverages:

Hydrogen hot coffee, hydrogen cold coffee, hydrogen hot tea, hydrogen cold tea, hydrogen water, etc.



健 禄

• 🖬 •

• 🔛 • • 🖬 • • 🖬 •

-

2-water.

Simple maintenance, easy to operate

Related parts can be disassembled to clean separately. Easy to maintain

Hydrogen beverage vending machine

| Ν | Aodel | H2 KC1 | |
|-----------------------|-------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|--|
| Beverage types | | Hot beverage: 4 options Cold beverage: 4 options Water : 3 options (hot, cold, iced) | |
| Function | Hot beverages | Water tank capacity : 5.6L Supplied water TEMP : 20°C 80ml/cup Approx. : 400 cups + (Generated TEMP : 70°C or higer | |
| | Cold beverages | Cooling system: Cooling pipe connected to cooling tank Supplied water TEMP : 25°C 80ml/cup Approx. : 180 cups + (Generated TEMP: 10°C or lower | |
| | Material | 800ml x 4 | |
| Cooling compre | | Hermetic cooling compressor (Refrigerant HFC-134a 70g) | |
| Capability | Rated power | Beverage supply : AC100V 50/60Hz 1040w 50/60Hz 175/190w | |
| | Concentration | 1.0ppm or more (hot and cold water side) | |
| D. T. | Water supply and drainage method | Directly connect to water source / drain | |
| D Type (Body only) | Dimensions | L 450mm x W 515mm x H 880mm | |
| (Body only) | Weight | 37kg | |
| D T | Water supply and drainage method | Directly connect to water source / drain | |
| P Type (CAT-10LW) | Dimensions | L 450mm x W 515mm x H 1,530mm | |
| | Weight | 53kg | |
| TTurna | Water supply and drainage method | Water supply at bottom / container | |
| T Type (CT-33LW) | Dimensions | L 450mm x W 515mm x H 1,530mm | |
| (| Weight | 61kg | |





Good taste and high hydrogen concentration

High-performance purification function ensures water safe and good taste.




Freely select and set up your preferred types of tea and coffee



Perfectly suited to lease and other business purpose.

Unique portable hydogen gas injection equipment 🐖 Inject ultra-high concentration hydrogen gas for bottled beverages



AYS

国際基準 IHSA 規格適合製品

It is also suitable for home use as well, especially for the elderly and severely ill people who cannot drink a lot of water due to their physical conditions. Days will be a perfect choice.



Unique hydrogen gas injection brand

It only takes 3 seconds to generate high-concentration hydrogen mineral water, hydrogen hot water, hydrogen hot tea, hydrogen hot coffee, hydrogen hot milk, hydrogen iced juice and other flavor beverages without being affected by temperature and water quality.

> No need to set up

various hydrogen beverages

Only takes 3 seconds to finish injection

The purity of hydrogen is over 99.9%. Hydrogen concentation can reach 3~10ppm by adjusting the pressure.



Instantly generate various of high-concentration hydrogen beverages without being affected by water temperature, such as hydrogen juice, hydrogen milk, hydrogen tea, hydrogen coffee, hydrogen mineral water, etc.



Reusable dedicated cap with a check valve

This dedicated cap with a check valve is designed for DAYS.

Its small top hole prevents air from entering bottle, keeping the bottle at a high pressure state and maintaining high hydrogen concentration for a longer time.

Hydrogen gas injection is simple and easy to operate





① Connect the (2) Turn on the dedicated bottle pressure button of DAYS, inject cap with the coupling part of hydrogen gas DAYS. about 3 sec.

③Put on the bottle cap, shake the bottle to completely dissolve hydrogen gas.









Desktop type, compact size, light weight, no power required, easy to carry

DAYS is not only suitable for indoors such as restaurants, bars, but also outdoor activities such as picnics and camping without a power supply requirement. It is suitable for both commercial and home use.

Stable pressure and safe operation

Standard hydrogen concentration renge: 3ppm ~ 10ppm For special request, it can be adjusted down to 1.6ppm, up to 16 ppm.



Suitable for many people continuous use

This bottle with the dedicated cap is easy to carry, suitable for membership facilities such as gyms, golf clubs, beauty salons, yoga studios and hot spring clubs, etc.





| Model | TM-1 | |
|---------------------------------|------------------------------------|------------|
| Dimension | W110 x D230 x H360 | |
| Weight | 5kg (Inclusive of 200L hydro | ogen tank) |
| Rated voltage | AC100V (When using the heater) | |
| Rated frequency | $50 Hz \sim 60 Hz$ | |
| Hydrogen generation pressure | ¹ Standard 2~3 atm (Max | 9atm) |
| Dissoving hydrogen concentation | 1.6ppm~10ppm + 💥 | |
| Color | Silver | |

 $\ensuremath{\mathbbmm}$ This data of hydrogen water concentration is provided by JHyPA (Japanese Molecule Hydrogen Promotion Association) Measuring method: Gas Chromatography (GC)

While continuing to develop our own new technologies, we *Doctors Man* are also committed to cooperating with the authoritative medical and research institutions in Japan to conduct medical research.



Our mission is to continuously develop the world's top technologies based on scientific facts and medical research, to promote hydrogen industry development, contributing to human health with more effective products.

While continuing to develop our own new technologies, we are also committed to cooperating with the authoritative research and medical institutions in Japan to conduct medical research to contribute to the common development of medical research and hydrogen industry.

In order to develop safer and more effective hydrogen products, we strive for excellence in quality with the spirit of craftsmanship, and constantly explore the world's latest technological fields.



Doctors Man's technicians have focused on hydrogen technology research for decades with craftsmanship spirit. Doctors Man's leading product technology is the crystallization of their wisdom and experience. As a pioneer in the hydrogen industry. Doctors Man not ony continuously challenge the world's latest technological difficulties to develop new products, but also having supported other companies to upgrade their technologies in recent years.

Doctors Man cooperates with Japan's authoritative hydrogen medical research institutions to jointly carry out hydrogen medical research to promote the common development of medical research and hydrogen industry.



Emergency & Disaster medicine / Battlefield In the hospital

Diverse medical fields contributed by H₂ medicine



Resuscitation of Marginal Donor Organs Following Circulatory Arrest **Development of Hydrogen-Rich Organ Preservation Solution Using**

Hydrogen-absorbing Alloy Canisters

A research team at the Keio University School of Medicine, led by Project Professor Eiji Kobayashi and Associate Professor of Cardiology Motoaki Sano, through joint research with Doctorsman Co., Ltd. (President So Hashimoto), has shown that by quickly injecting hydrogen gas into an organ preservation solution¹, an injured organ removed from an older miniature pig (donor) can be resuscitated and used as

a transplant organ, even after circulation has ceased for a certain period of time.


🔀 Keio University

October 2, 2019


Keio University School of Medicine



Main joint research institutions



Doctors Man's patented technology





Separation Electrolyzer This core hydrogen generation electrolyzer is originally developed by Doctors Man. It is a hydrogen and oxygen separation unit. It has ultra-high stable hydrogen generating capacity at least 12,000 liters of water, which means it can reach about 10 years or more service life. There are two types: Pressurized hydrogen gas dissolution type and Water electrolytic dissolution type.

* Patent No. : 6371489

is as high as 2.4-3.6ppm.

* Patent No. : 6185445

Hydrogen concentration indicator

* Patent No. : 6521773

Portable hydrogen gas injector

The patented technology of alloy pressure storage hydrogen tank is an epoch-making new technology. In addition to patented technology of check valve, the perfect combination of these two technologies has formed this unique brand

* Patent No. : 5710039 * Patent No. : 5710050

Prevention of air backflow check valve integrated bottle cap

After high pressure hydrogen gas is injected into bottled water, this vacuum check valve cap can maintain the stability of internal pressure and prevent air from entering the bottle, so that the concentration of hydrogen gas dissoved in water will not drop.

* Design Registration No. : 1552712

Dedicated hydrogen water storage container H2-BAG

This dedicated hydrogen water storage container can keep hydrogen concentration for 7 days. Its internal structure and check valve are patented technologies.

* Patented in : Japan , USA , China Mainland, Hong Kong , Taiwan , and Korea











16





Pressurized Dissolution Nano Bubbling System

The patented special hollow-fiber membrane allows only hydrogen gas to permeate, so that the purity of hydrogen can reach more than 99.99%, which ensures hydrogen water safer and higher purity. Pressurized structure and special nanotechnology ensure that hydrogen water concentration

*Dissolved hydrogen concentration test : 60 ℓ /hour x continuous water discharge 8 hours = 480 ℓ

Hydrogen generation core : Doctors Man Hydrogen and Oxygen

This figure shown on the indicator is a real-time detected actual dissolved concentration, so consumers can observe the actual concentration of hydrogen water when drinking instead of the theoretically measured concentration. By this indicator, we have solved the problem that users are not able to accurately measure the concentration of hydrogen water.

Business Locations and Japan Domestic Sales Status

Adopted by over

Institutions

2

300



(1) Doctors Man Headquarters



(2) Kansai Branch and Plant



(3) Technology R&D Center



(4) Maintenance Center

Company Profile

| Name of Corporation | Doctors Man Co., L | |
|-------------------------------|--------------------|----------|
| Representative of Corporation | President | So Hashi |
| Established Year | 2005 | |

Patent Certificates







1124 11 21 2 ROMER 0012 0 6 8 22 8 4 4 001 4 9 4 8 22 8 5 7

Adoption Examples

Distribution Map

• Sports Institutions Medical Institutions • Comercial Institutions

* As of Aug. 1st., 2020

Adopted by Sports Institutions





• Adopted by Commercial Institutions







GU




X









 $\overline{-(4)}^{(1)}$





Adopted by Medical Institution

himoto

